

Assembly Instructions

# BRONTE ARMCHAIR



## *Hardware*

1-1/4" flat washer (H1)

## *Assembly*

1. Lay down your armchair to attach the legs.
2. Prepare the legs. Remove the plastic caps and use a 1-1/4" flatwasher (H1) to attach the legs to the armchair.
3. Place the armchair on a flat surface. If the armchair is not level, add an additional 1-1/4" flatwasher (H1) after unscrewing the shortest leg.

Note: You may have extra H1 washers left over, depending on how many you used to level the armchair.

SHARLAND  
ENGLAND