

## Assembly Instructions

# VICTORIA SETTEE



### *Hardware*

1-1/4" flat washer (H1)  
5/16" nut (H2)

### *Assembly*

1. Join the seat and the back of the settee together, making sure they are aligned.
2. Place one 1-1/4" flat washer (H1) on the stud, then top with a 5/16" nut (H2) and tighten.
3. Prepare the legs. Remove the plastic caps and use a 1-1/4" flatwasher (H1) to attach the legs to the settee.
4. Place the settee on a flat surface. If the settee is not level, add an additional 1 1/4" flatwasher (H1) after unscrewing the shortest leg.

Note: You may have extra H1 washers left over, depending on how many you used to level the settee.